



Installation Guide

Recommended Tools For Decking Installation



Drill



Level



Measuring Tape



C Clamp



#10 or #12
Button Head
Hardware



1/8" Spacer

Building Code and Safety Conduct:

Adhere to all local building codes and safety guides set forth by the local government. Please refer to state and local law for more information on the permit(s) and safety instructions.

Hardware:

Recommended hardware for installation is a #10 or #12 button head stainless steel screw. When fastening panels onto the subframe, note that there is no need to predrill the decking panels. Hardware, when screwed needs to be flush to the bottom of the pocket. Over-tightening may result in damage to the panel, or not properly being fastened.

Gapping:

Gapping between panels is necessary to allow for thermal expansion and contraction. A 1/8-in gap between panels will provide room for expansion in most environments.


Decking Placement

The Snap Decking panel must be perpendicular to the direction of travel. Follow the step-by-step guide provided for instruction.

Correct



Incorrect



WARNING

Decking Panels Should Be Set In Place By Hand.
DO NOT KICK PANELS INTO PLACE.



1-800-768-9108



sales@snapdecking.com




11405 N. Pennsylvania St.
Suite 106, Camel, IN, 46032

Step 1:

Equally space the deck joints based on the Snap Decking panels purchased.



- 18" centers (3' panels)
- 16" or 24" centers (4' panels)
- 15" or 20" centers (5' panels)

Note: Illustration shown is based on a 3' panel.



Step 2:

Fasten the panel to the subframe using a drill and the appropriate #10 or #12 button head stainless steel screws. Do not over-tighten, make the screw snug with interior of the screw pocket.



Close up view of the screw pocket


Step 3:

Using the interlocking system, place the remaining panel onto the frame and repeat the same installation process as in step 2 until project is complete.

Note: 1/8" gap between panels will provide room for expansion in most environments.



1/8"
Gapping



Step 4:

Your Snap Decking Installation is now complete.

Note: Illustration shows a fully installed deck using 3' panels.